


OysterMouse Instructions

Get started:

Understand the mechanical functions before using your OysterMouse. Open the OysterMouse to a position you find comfortable. If you want to close the mouse or reduce the angle, first open to *released position* (see illustration to the right).

Connecting the OysterMouse:


Connect your OysterMouse to an USB port on your computer. The OysterMouse is compatible with Windows up to Win7. The copy/paste functions are not supported on a Mac.



closed position

In order to close the mouse FIRST OPEN to *released position*! If too much force is used when pressing the top of the mouse down without releasing mechanism first, the joint might break. In this case damage is not covered by warranty.
Warranty does NOT cover misuse.

Switch Mode



Button functions

Right hand



Left hand



Right and left hand mode



ergoption
OysterMouse manual



www.bakkerelkhuizen.com