

Støvsugerpose | Egnet Philips, Electrolux

General information

Erstatningsdele til: Philips Standard Bag, Electrolux

Indholdet i pakken:
4x stdiameterpose
1x motorfilter

Specifications

Antal motor 1
filtre:
Antal 4
støvsugerposer:
Materiale: Synthetic



Sales information

Order code: **DUBG220AEP4**
Product description: Støvsugerpose | Egnet Philips, Electrolux
Packaging: Giftbox with eurolock
Brand name: Nedis



Quantity	LxWxH (mm)			Weight
1	170 mm	50 mm	240 mm	200 g
20	435 mm	230 mm	480 mm	4600 g

UltraSilencer USENERGY / A.E.G.

UltraSilencer USORIGINDB / A.E.G.

UltraSilencer USORIGINPR / A.E.G.

UltraSilencer USORIGINWR / A.E.G.

UltraSilencer USPARKETTO / A.E.G.

UltraSilencer USREMOTE / A.E.G.

VivaControl AVC 1110...1190 / A.E.G.

VivaControl AVC 1220 / A.E.G. VivaControl

AVC 1221...1230 / A.E.G. VivaQuickstop AVQ

2100...2190 / Electrolux AirMax ZAM

6100...6199 / Electrolux AirMax ZAM

6210...6290 / Electrolux AirMax ZAM 6220 /

Electrolux AirMax ZAM 6230 / Electrolux

Airmax ZAM 6210 / Electrolux Airmax ZAM

6240 / Electrolux Airmax ZAM 6250 /

Electrolux Bolido Z 4500...4595 / Electrolux

Clario Z 1900...2095 / Electrolux ErgoBox

XXL TT 11 / Electrolux ErgoBox XXL TT 12 /

Electrolux ErgoBox XXL TT 14 / Electrolux

ErgoSpace Green ZEG 301 / Electrolux

ErgoSpace Green ZEG300 / Electrolux

ErgoSpace XXL 10...300 / Electrolux

ErgoSpace XXL 2253 / Electrolux ErgoSpace

XXL 2254 / Electrolux ErgoSpace XXL 2271 /

Electrolux ErgoSpace XXL 2272 / Electrolux

ErgoSpace ZE 2200...2299 / Electrolux

ErgoSpace ZE 305...361 / Electrolux

Essensio ZEO 5400...5499 / Electrolux

Essensio ZEO 5420 / Electrolux Excellio Z

5000...5295 / Electrolux JetMaxx EL 4040A /

Electrolux Maximus EL 4200A / Electrolux

Maximus XXM 000...999 / Electrolux

Maximus ZXM 7010...7035 / Electrolux

Original E 15 / Electrolux Original E 18 /

Electrolux Original E 200 / Electrolux

Original E 201 / Electrolux Original E 202 /

Electrolux Original E 203 / Electrolux

Original E 205 / Electrolux Original E 206 /

Electrolux Original E 210 / Electrolux

Original E 40 / Electrolux Original E 53 /

Electrolux Original E 54S / Electrolux

Oxy3System EL 7020 / Electrolux

Oxy3System EL 7024 / Electrolux

Oxy3System ZO 6300...6399 / Electrolux

Oxygen EL 7062A / Electrolux Oxygen Z

5500...5695 / Electrolux Oxygen Z

5900...5995 / Electrolux UltraSilencer

4065OR / Electrolux UltraSilencer EL 7060A

DeepClean / Electrolux UltraSilencer EL

7061A/B DeepClean / Electrolux

UltraSilencer EL 7063A DeepClean /

Electrolux UltraSilencer EL 7066A

DeepClean / Electrolux UltraSilencer

USALLFLOOR / Electrolux UltraSilencer

USANIMAL / Electrolux UltraSilencer

USDELUXE / Electrolux UltraSilencer

USENERGY / Electrolux UltraSilencer

USGREEN / Electrolux UltraSilencer

USORIGINDB / Electrolux UltraSilencer

Stovsugerpose | Egned Philips, Electrolux

nedis

Støvsugerpose | Egned Philips, Electrolux